Operation and Safety Guide

CYCLONE Model # K81018

Vendor Website: www.inteccorp.com

Support Phone No. 800-666-1611

⚠ WARNING

SAFETY TOPICS:

To avoid personal injury, do not attempt to operate this equipment until you thoroughly read and completely understand the operator's manual. Please visit http://www.inteccorp.com/cyclone/ for additional information.

SAFETY CHECKLIST:

1) Read all the instructions before using the insulation blower.
2) To reduce the risk of injury, close supervision is necessary when an insulation blower is used near children.
3) Do not contact moving parts.
4) Only use attachments recommended or sold by the manufacturer.
5) Use of Extension and Power Cord:

a) This product requires the use of a power cord. In addition to the supplied power cord, care should be exercised in the selection and use of an extension cord.
b) The extension cord shall be a grounded 3-wire cord.
c) The extension cord should be arranged so that it will not drape over the countertop or tabletop where it can be tripped over, snagged, or pulled on unintentionally (especially by children).
d) An outdoor rated extension cord should be used with this machine. An outdoor- use extension cord is marked with suffix letter "W" and with a tag stating "Suitable for Use with Outdoor Appliances."
e) The marked electrical rating of the extension cord shall be rated for at least 15 amps.
f) To unplug or disconnect: Put the blower and agitator control panel and remote buttons in the stop position before removing plug from outlet.
g) Do not unplug by pulling on the power cord. To unplug, grasp the male and female plugs and pull apart.
h) Unplug from outlet when not in use and before servicing or cleaning.
i) Do not operate any insulation blower with a damaged cord or plug, or after the machine malfunctions or is dropped or damaged in any manner.

6) In the case of a non-operable or malfunctioning blower, return the insulation blower to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.

7) Store insulation blower indoors when not in use. Keep out of the reach of children
8) Never operate this equipment if the operator or the machine is standing in water, snow or rain. Do not clean this insulation blower with water spray or the like.
9) Connect to a properly grounded outlet only.

10) Wear long sleeve shirt, gloves, a hat, safety glasses or goggles, and a nose & mouth dust mask.

WARNING:

1) Never reach into the hopper when system is operating.
2) Keep all foreign materials out of hopper.
3) Stop all motors and disconnect power cord before attempting to remove a foreign object or jam.
4) Never point insulation hose in the direction of people or pets.

Tool Application: See operational video at
http://www.inteccorp.com/cyclone/

Tool Operation:

Step	Action
1	Unload the machine using safe lifting techniques. Position the machine in a dry, hazard free environment to allow for suitable material feed and access to electrical power.
2	Note: At cold temperatures below 35 F., oil thickens and will cause machine to start up hard. To prevent hard startup, leave machine in warm area overnight (8 hours).
3	Secure 100 feet of blowing hose to machine outlet with a hose clamp.
4	Remove slide gate locking pin, open the slide gate to the last hole position for attic blow & re-insert locking pin. (See owner's manual for wall applications.)
5	Ensure all controls are in the "off" position.
6	Use a 12-3 extension cord no longer than 50 feet to connect the machine's power cord to a dedicated circuit – 115V 20amp or 15amp.
7	To power machine, first turn the blower switch to the "on" position, then the agitator switch to the "on" position.
8	Now use the remote switches to first turn the blower, then agitator "on". When turning machine "off", turn agitator "off" first, then blower.
9	Open a bag of insulation and hand feed the insulation material into the hopper. Do not let the plastic bag or other foreign objects fall into the hopper; do not force feed insulation..
10	At completion, use the remote or panel switch to turn machine off.
11	Remove any insulation still in the system.
12	Make sure you return all parts and accessories when bringing machine, hose, and power cord (if supplied) to the rental center from which it was obtained.